


ThermaSkirt® COMFORT CONTROLLER



Congratulations on choosing a property heated by ThermaSkirt® - the skirting board that heats your home!

ThermaSkirt® has been independently tested and proven to be at least 13% more energy efficient than conventional radiators, and is more responsive and controllable than under-floor heating.

These simple steps will ensure you get the best possible comfort with minimal running costs.

These suggestions for your Comfort Controller settings are for guidance only and may be different depending on your particular circumstances, or weather conditions at the time.

- 1.**  **Wintertime:** At '12 o'clock' the system is fully open and running at maximum temperature and is suitable for Winter operation. Turn down to 2 o'clock if required.
- 2.**  **Spring & Autumn:** At between '3 and 5 o'clock' this is suitable for Spring & Autumn operation.
- 3.**  **Summer:** At '6 ~ 8 o'clock', this is suitable for summer running. Remember: ThermaSkirt® can respond in minutes to your heating requirements; simply turn the dial control anti-clockwise to '12 o'clock' to provide virtually instant room heating.
- 4.**  **Frost:**  If you're going away, you can leave the dial control on frost, to ensure your pipes don't freeze and cause a burst.
- 5.**  **OFF:** Should only ever be used for any maintenance or servicing. Note: the 'lockshield' valve must also be turned fully clockwise with a screwdriver to shut off the flow completely.